


4260 AIR HAMMER

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	RC5260A-01	Handle	1	18	RC5260A-18	Lever Roller Pin	1				
2	RC5260A-02	Cylinder 5X	1	19	RC5260A-19	Stopper Pin	1				
3	RC5260A-03	Piston	1	20	RC5260A-20	Exhaust Cover	1				
4	RC5260A-04	Bush	1	21	RC5260A-21	Retainer Spring	1				
5	RC5260A-05	Valve Box	1	22	RC5260A-22	Bee Hive Spring	1				
6	RC5260A-06	Valve	1								
7	RC5260A-07	Pin	1								
8	RC5260A-08	Valve Seat	1								
9	RC5260A-09	Throttle Bush	1								
10	RC5260A-10	Inlet Bushing	1								
11	RC5260A-11	Valve Stem	1								
12	RC5260A-12	O-Ring	1								
13	RC5260A-13	Spring	1								
14	RC5260A-14	Plug	1								
15	RC5260A-15	Lever Roller Pin	1								
16	RC5260A-16	Handle Knock Pin	1								
17	RC5260A-17	Assistant Lever	1								

FOOTNOTES

When ordering spare parts, please specify tool type, part number and description.

EAGLE

10000 SE PINE ST., PORTLAND, OR 97216
503-254-6600 FAX 503-254-7215

REVISED 3/12