


5800EC LOW SPEED TIRE BUFFER WITH EXHAUST HOSE

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	4025001	Plug Screw	1	20	4025020	Rotor Blade	4
2	4025002	O-Ring	1	21	4025021	Rotor	1
3	4025003	O-Ring	1	22	4025022	Cylinder	1
4	4025004	Air Regulator	1	23	4025023	Rotor Collar	1
5	4025005	Valve Spring	1	24	4025024	Ball	1
6	4025006	O-Ring	1	25	4025025	Bearing Plate	1
7	4025007	Valve Stem	1	26	4025026	Bearing	1
8	4025008	O-Ring	1	27	4025027	Internal Gear	1
9	4025009	Motor Housing	1	28	4025028	Planetary Gear	3
10	4025010	Valve Bushing	1	29	4025029	Needle Bearing	3
11	4025011	O-Ring	2	30	4025030	Pin	3
12	4025012	Muffer	1	31	4025031	Idler	1
13	4025013	Air Inlet	1	32	4025032	Bearing	2
14	4025014	Lever	1	33	4025033	Bearing	2
15	4025015	Lever Pin	1	34	4025034	Housing Cap	1
16	4025016	Steel Plate	1	35	4025035	QC Chuck	1
17	4025017	Bearing	1	36	4025036	Nut	1
18	4025018	Bearing Plate	1	37	4025037	Muffer Hose	1
19	4025019	Ball	1	38	4025038	Retaining Ring	1

NOTES

When ordering spare parts, please specify tool type, part number and description.

10000 SE PINE ST., PORTLAND, OR 97216
503-254-6600 FAX 503-254-7215

