


# 5801EC LOW SPEED TIRE BUFFER WITH EXHAUST HOSE

## EXPLODED VIEW



## PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	4040001	Plug Screw	1	21	4040021	Rotor	1
2	4040002	O-Ring	1	22	4040022	Cylinder	1
3	4040003	O-Ring	1	23	4040023	Rotor Collar	1
4	4040004	Air Regulator	1	24	4040024	Ball	1
5	4040005	Valve Spring	1	25	4040025	Bearing Plate	1
6	4040006	O-Ring	1	26	4040026	Bearing	1
7	4040007	Valve Stem	1	27	4040027	Internal Gear	1
8	4040008	O-Ring	1	28	4040028	Planetary Gear	3
9	4040009	Motor Housing	1	29	4040029	Needle Bearing	3
10	4040010	Valve Bushing	1	30	4040030	Pin	3
11	4040011	O-Ring	2	31	4040031	Idler	1
12	4040012	Muffler	1	32	4040032	Bearing	1
13	4040013	Air Inlet	1	33	4040033	Bearing	1
14	4040014	Lever	1	34	4040034	Housing Cap	1
15	4040015	Lever Pin	1	35	4040035	QC Chuck	1
16	4040016	Steel Plate	1	36	4040036	Nut	1
17	4040017	Bearing	1	37	4040037	Muffler Hose	1
18	4040018	Bearing Plate	1	38	4040038	Retaining Ring	1
19	4040019	Ball	2				
20	4040020	Rotor Blade	4				

### NOTES

When ordering spare parts, please specify tool type, part number and description.

10000 SE PINE ST., PORTLAND, OR 97216  
503-254-6600 FAX 503-254-7215

