


EPTS-33023-25Q TORQUE CONTROLLED SCREWDRIVER

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty	Index Number	Part Number	Description	Qty.
1	EPTS-33023-25Q-1	Housing Assembly (incl. 4)	1 ●	41	EPTS-33023-25Q-41	Cam Ring	1
2	EPTS-33023-25Q-2	Reverse Valve	1	42	EPTS-33023-25Q-42	Washer	1
3	EPTS-33023-25Q-3	Spring	1	44	EPTS-33023-25Q-44	Spring Holder	1
4	EPTS-33023-25Q-4	Reverse Valve Bushing	1 ▲	46	EPTS-33023-25Q-46	Adjustment Nut	1
5	EPTS-33023-25Q-5	Pin	1	47	EPTS-33023-25Q-47	Adjustment Lock Ring	1
6	EPTS-33023-25Q-6	Throttle Valve Plunger	1	48	EPTS-33023-25Q-48	Retainer	1
7	EPTS-33023-25Q-7	Bearing	2	49	EPTS-33023-25Q-49	Bushing	1
8	EPTS-33023-25Q-8	Rear End Plate	1	50	EPTS-33023-25Q-50	Bit Sleeve	1
9	EPTS-33023-25Q-9	Cylinder	1	51	EPTS-33023-25Q-51	Spring	1
10	EPTS-33023-25Q-10	Pin	2	52	EPTS-33023-25Q-52	Washer	1
11	EPTS-33023-25Q-11	Rotor Blade	4	53	EPTS-33023-25Q-53	Retainer	1
13	EPTS-33023-25Q-13	Front End Plate	1	54	EPTS-33023-25Q-54	Air Inlet	1
14	EPTS-33023-25Q-14	Pin	1	55	EPTS-33023-25Q-55	Exhaust Deflector	1
17	EPTS-33023-25Q-17	Pin	3	56	EPTS-33023-25Q-56	Muffler Element	1
22	EPTS-33023-25Q-22	Gear Housing	1	57	EPTS-33023-25Q-57	Spring	1
23	EPTS-33023-25Q-23	Bearing	1	58	EPTS-33023-25Q-58	Steel Ball	1
24	EPTS-33023-25Q-24	Retainer	1	59	EPTS-33023-25Q-59	O-Ring	1
25	EPTS-33023-25Q-25	Hammer Case	1	60	EPTS-33023-25Q-60	Screwdriver	1
26	EPTS-33023-25Q-26	Adjustment Cover	1	61	EPTS-33023-25Q-61	Bit (Option)	1
27	EPTS-33023-25Q-27	Hanger	1	62	EPTS-33023-25Q-62	Rotor	1
28	EPTS-33023-25Q-28	Spring	1	70	EPTS-33023-25Q-70	Second Gear Cage Spacer	1
29	EPTS-33023-25Q-29	Snap Ring	1	71	EPTS-33023-25Q-71	Planet Gear	3
30	EPTS-33023-25Q-30	Cam Spindle	1	72	EPTS-33023-25Q-72	Second Gear Cage	1
31	EPTS-33023-25Q-31	Ball Holder	1	73	EPTS-33023-25Q-73	Spring	1
32	EPTS-33023-25Q-32	Steel Ball	18	TK	EPTS-33023-25Q-TK	Tune-Up Kit { incl. 3.6 .7 (2) .11 (4).23.28.30. 32 (18) . 33.34.35 (3) .36.38 (3) .39.40 (3) .47.51.56.57.58.59.73 }	
33	EPTS-33023-25Q-33	Driving Shaft	1				
34	EPTS-33023-25Q-34	Pin	1				
35	EPTS-33023-25Q-35	Steel Ball	3				
36	EPTS-33023-25Q-36	Spring	1				
37	EPTS-33023-25Q-37	Standard Anvil	1				
38	EPTS-33023-25Q-38	Pin	3				
39	EPTS-33023-25Q-39	Band	1				
40	EPTS-33023-25Q-40	Steel Ball	3				

FOOTNOTES

- Must be Purchased in Assembly Set
- ▲ Recommended not to be purchased alone due to assembly difficulty

EPT

10000 SE Pine Street
Portland, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify
tool type, part number and description.