


# EPTS-34008-25Q TORQUE CONTROLLED SCREWDRIVER

## EXPLODED VIEW



## PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty	Index Number	Part Number	Description	Qty
1	EPTS-34008-25Q-1	Housing Assembly ( incl. 4 )	1 ●	34	EPTS-34008-25Q-34	Pin	1
2	EPTS-34008-25Q-2	Reverse Valve	1	35	EPTS-34008-25Q-35	Steel Ball	3
3	EPTS-34008-25Q-3	Spring	1	36	EPTS-34008-25Q-36	Spring	1
4	EPTS-34008-25Q-4	Reverse Valve Bushing	1 ▲	37	EPTS-34008-25Q-37	Standard Anvil	1
5	EPTS-34008-25Q-5	Pin	1	38	EPTS-34008-25Q-38	Pin	3
6	EPTS-34008-25Q-6	Hanger	1	39	EPTS-34008-25Q-39	Band	1
7	EPTS-34008-25Q-7	Bearing	1	40	EPTS-34008-25Q-40	Steel Ball	3
8	EPTS-34008-25Q-8	Rear End Plate	1	41	EPTS-34008-25Q-41	Cam Ring	1
9	EPTS-34008-25Q-9	Cylinder	1	42	EPTS-34008-25Q-42	Washer	1
10	EPTS-34008-25Q-10	Pin	2	43	EPTS-34008-25Q-43	Spring	1
11	EPTS-34008-25Q-11	Rotor Blade	5	44	EPTS-34008-25Q-44	Spring Holder	1
12	EPTS-34008-25Q-12	Rotor	1	46	EPTS-34008-25Q-46	Adjustment Nut	1
13	EPTS-34008-25Q-13	Front End Plate	1	47	EPTS-34008-25Q-47	Adjustment Lock Ring	1
14	EPTS-34008-25Q-14	Pin	1	48	EPTS-34008-25Q-48	Retainer	1
15	EPTS-34008-25Q-15	Bearing	1	49	EPTS-34008-25Q-49	Bushing	1
16	EPTS-34008-25Q-16	Spacer	1	50	EPTS-34008-25Q-50	Bit Sleeve	1
17	EPTS-34008-25Q-17	Middle Gear	1	51	EPTS-34008-25Q-51	Spring	1
18	EPTS-34008-25Q-18	Planet Gear	3	52	EPTS-34008-25Q-52	Washer	1
19	EPTS-34008-25Q-19	Pin	6	53	EPTS-34008-25Q-53	Retainer	1
20	EPTS-34008-25Q-20	First Gear Cage	1	54	EPTS-34008-25Q-54	Hammer Case	1
21	EPTS-34008-25Q-21	Gear Cage Spacer	1	55	EPTS-34008-25Q-55	Adjustment Cover	1
22	EPTS-34008-25Q-22	Planet Gear	3	56	EPTS-34008-25Q-56	Air Inlet	1
23	EPTS-34008-25Q-23	Second Gear Cage	1	57	EPTS-34008-25Q-57	Exhaust Deflector	1
24	EPTS-34008-25Q-24	Washer	1	58	EPTS-34008-25Q-58	Throttle Valve Plunger	1
25	EPTS-34008-25Q-25	Gear Housing	1	59	EPTS-34008-25Q-59	Muffler Element	1
26	EPTS-34008-25Q-26	Bearing	1	60	EPTS-34008-25Q-60	Spring	1
27	EPTS-34008-25Q-27	Retainer	1	61	EPTS-34008-25Q-61	Steel Ball	1
28	EPTS-34008-25Q-28	Spring	1	62	EPTS-34008-25Q-62	O-Ring	1
29	EPTS-34008-25Q-29	Snap Ring	1	63	EPTS-34008-25Q-63	Screwdriver	1
30	EPTS-34008-25Q-30	Cam Spindle	1	64	EPTS-34008-25Q-64	Bit ( Option )	1
31	EPTS-34008-25Q-31	Ball Holder	1	TK	EPTS-34008-25Q-TK	Tune-Up Kit { incl. 3.7 .11 ( 5 ) .15.26.28.30.32 ( 18 ) .33. 34.35 ( 3 ) .36.38.39.40 ( 3 ) .43.47.51.56.57.58.59.60.61.62 }	
32	EPTS-34008-25Q-32	Steel Ball	18				
33	EPTS-34008-25Q-33	Driving Shaft	1				

### FOOTNOTES

- Must be Purchased in Assembly Set
- ▲ Recommended not to be purchased alone due to assembly difficulty

# EPT

10000 SE Pine Street  
Portland, OR 97216  
503-254-6600  
FAX 503-255-2615

When ordering spare parts, please specify  
tool type, part number and description.